


# SUPERSTAR Accessories, source and fitting instructions



## Source Options

The SUPERSTAR comes with three shelf options to accommodate your chosen source. Mount the shelf which best suits your source using the screws supplied.

### Shelf 1

Front or side mounting option. Ideal for small – medium digital source and docking station

### Shelf 2


Side mounting only. This pocket design is ideal for sources such as mobile phones without docking stations

### Shelf 3

Side mounting only. Large shelf for larger sources

the SUPERSTAR is compatible with any digital source, including:

iPod®, iPhone®, AirPort Express®, Archos®, Sonos®, Squeezebox®, Bose®, B&O®



We highly recommend the use of a purpose designed docking station no matter what the type or brand of MP3 player, or other source.

**Note** that by using the mini jack straight out of the source, the audio output in some cases will be limited. In most cases this can be eliminated by using a docking station or a purpose made output connector, such as a multi pin connector to RCA.

## SUPERSTAR adjustable wall mount bracket

### Fitting Instructions:

Using screws and fixings suitable for your wall type (not supplied) mount the Wall Bracket to the desired height.

Decide where the top of your SUPERSTAR should be and measure down for the wall bracket position, the screw holes of the wall bracket are 126mm from the top of the SUPERSTAR. Once the Wall Bracket is securely fixed hook the Speaker Bracket over the Wall Bracket. The curved edge of the Speaker Bracket allows for levelling adjustment – take the weight of the SUPERSTAR and then carefully straighten the unit. Once straight release the unit and the bracket locks in to place.

